

How to make your own... coat hanger peg board

- Take an off cut of plyboard and cut it to the size you require.
- Start your measurements.
- Leave a 50mm border around the exterior of the ply board.
- Then in rows mark out where your holes will be, leaving a 100mm gap between each hole.
- Drill out each hole (the same width as the dowel that will be inserted) to a depth of 15mm.
- Sand down the plyboard and each individual hole - use a bike pump to remove any excess sawdust from the holes.
- Cut all your dowels to the same length and sandpaper the ends for a smooth finish.
- Apply any appropriate stains to colour the plyboard allow to dry and then fine sand.
- Seal the ply board with two coats of waterborne urethane and allow to dry for 72 hours.